


REAR NO. 1 SUSPENSION ARM

COMPONENTS



REAR NO. 1 SUSPENSION ARM ASSEMBLY LH

SP

REMOVAL



HINT:

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.

1. REMOVE REAR WHEEL

2. REMOVE REAR NO. 1 SUSPENSION ARM ASSEMBLY LH

- (a) Support the No. 2 suspension arm LH.



- (b) Remove the bolt and 2 nuts from the suspension member and axle carrier.

HINT:


While fixing the nut in place, loosen and remove the bolt from the suspension member side.

- (c) Using SST, disconnect the suspension arm from the axle carrier.

SST 09610-20012

NOTICE:

Do not damage the dust cover.



INSPECTION

1. INSPECT REAR NO. 1 SUSPENSION ARM ASSEMBLY LH

- (a) As shown in the illustration, move the ball joint stud back and forth 5 times before installing the nut.
- (b) Using a torque wrench, turn the nut continuously at a rate of 2 to 4 seconds per turn and take the torque reading on the fifth turn.

Standard turning torque:


3.4 N*m (35 kgf*cm, 30 in.*lbf)

- (c) Check for any cracks and grease leaks on the ball joint dust cover.

INSTALLATION

HINT:

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.



1. TEMPORARILY TIGHTEN REAR NO. 1 SUSPENSION ARM ASSEMBLY LH

- (a) Temporarily install the suspension arm with the bolt and 2 nuts to the suspension member and axle carrier.

2. INSTALL REAR WHEEL

- (a) Install the wheel.
Torque: 103 N*m (1,050 kgf*cm, 76 ft.*lbf)

3. TIGHTEN REAR NO. 1 SUSPENSION ARM ASSEMBLY LH

- (a) Install the nut and 2 bolts.
Torque: 90 N*m (918 kgf*cm, 66 ft.*lbf) for bolt
100 N*m (1,020 kgf*cm, 74 ft.*lbf) for nut

NOTICE:

For the nut on the rear suspension member side, do not tighten the nut.

4. INSPECT AND ADJUST REAR WHEEL ALIGNMENT

- (a) Inspect and adjust the rear wheel alignment (see page [SP-7](#)).